

E190-E2 COLLINS

NACELLE TOOLING CATALOG

NACELLE

TOOLING by

DEDIENNE AEROSPACE



E190-E2 GSE TOOLS


We have the capability to provide you all recommended GSE's based on the Aircraft Maintenance Manual (AMM) for your EIS (Entry-into-Service) program, and all your maintenance operations.

Thanks to our Tooling recommendation team, we can propose you a tailored tooling list for your maintenance workscope.




CATEGORY	PART NUMBER	NAME	MINIMAL QT FOR EIS
 INLET COWL	347-1100-1GSE	Inlet Cowl Sling	1
	347-1100-2GSE	Inlet Cowl Dolly	1
	347-1100-3GSE	Inlet Protective Rug	0
	347-1100-4GSE	Inlet Cowl Cover	2
 FAN COWLS	347-2000-1GSE	Fan Cowl Sling	1
	347-2000-2GSE	Fan Cowl Dolly	2
	347-2000-3GSE	Fan Cowl Vent Plug	0
	347-2000-5GSE	Fan Cowl Hinge Bolt Thread Protectors	1
 THRUST REVERSER	347-3001-1GSE	Thrust Reverser Sling - LH/RH	1
	347-3001-2GSE	Thrust Reverser Towable Dolly- LH/RH	2
	347-3001-3GSE	Thrust Reverser Beam Bolt Thread Protector	0
	347-3001-5GSE	Thrust Reverser Plug	2
	347-3001-7GSE	Thrust Reverser Door Opening System, Hand Pump	1
	347-3001-11GSE	Thrust Reverser Unlock Pins - LH/RH	0
	347-3001-14GSE	Thrust Reverser PRD Torque Adaptor	1
 NOZZLE & CENTER BODY	347-4100-1GSE	Exhaust Nozzle Cover	2
	347-4100-4GSE	Exhaust Nozzle Lifting Aid	1
 ENGINE MOUNT	347-6000-1GSE	Engine Mount Cart	0
	347-6001-2GSE	Forward Engine Mount Sling	1
	347-6501-1GSE	Aft Engine Mount Sling	1

CONTENT



INLET COWL

- > Inlet Cowl Door Slings p.4
- > Inlet Cowl Dolly p.5
- > Inlet Protective Rug p.6
- > Inlet Cowl Cover p.7




FAN COWLS

- > Fan Cowl Slings p.16
- > Fan Cowl Dolly p.17
- > Fan Cowl Vent Plug p.18
- > Fan Cowl Hinge Bolt Thread Protectors p.19




THRUST REVERSER

- > Thrust Reverser Slings - LH/RH p.8
- > Thrust Reverser Towable Dolly - LH/RH p.9
- > Thrust Reverser Beam Bolt Thread Protector p.10
- > Thrust Reverser Plug p.11
- > Thrust Reverser Door Opening System, Hand Pump p.12
- > Thrust Reverser Unlock Pins - LH/RH p.13
- > Thrust Reverser PRD Torque Adaptor p.14
- > Translating Sleeve Dolly p.15



NOZZLE & CENTER BODY

- > Exhaust Nozzle & Centerbody Cover p.20
- > Exhaust Nozzle Lifting Aid p.21



ENGINE MOUNT

- > Engine Mount Cart p.22
- > FWD Engine Mount Slings p.23
- > AFT Engine Mount Slings p.24



INLET COWL SLING

DESCRIPTION - USE

The Inlet Cowl Sling is used to lift and move the entire E190-E2 Inlet Assy.

CAUTION

The Inlet Cowl Sling is used to install or remove the Inlet Cowl from the Engine. This tool has a feature that allows the tool operator to rotate the Inlet Cowl and eases the installation on the Engine or placement on the Dolly.

TEST

Dedienne Aerospace has regional facilities to aid in the required annual testing and recertification.

DIMENSIONS

2700 x 450 x 450 mm
[107 x 18 x 18 in]

WEIGHT

82 kg [181 lbs]



The pictures, measurements, and weights shall be used only as an indication.




INLET COWL DOLLY

DESCRIPTION - USE

This tool is used during the maintenance and transportation of inlet cowl.

CAUTION

This tool has been validated for the maintenance of the E190-E2 Inlet Cowl. If the Inlet Cowl is moved or repaired on another tool and there is damage, the insurance company may not cover the damage.



DIMENSIONS
2800 x 1650 x 1700 mm
[111 x 65 x 67 in]

WEIGHT
900 kg [1,984 lbs]

The pictures, measurements, and weights shall be used only as an indication.

5

347-1100-2GSE



A220 GSE TOOLS



INLET PROTECTIVE RUG

DESCRIPTION - USE

Tool is used as a Protective Mat on the Inlet inner surface during Maintenance, Removal or Installation activity on the Inlet.



DIMENSIONS
850 x 400 x 200 mm
[34 x 16 x 8 in]

WEIGHT
10 kg [23 lbs]

The pictures, measurements, and weights shall be used only as an indication.

6

347-1100-3GSE

A220 GSE TOOLS



INLET COWL COVER

DESCRIPTION - USE

The Inlet Cowl Cover is used to protect inlet from foreign objects during parking and mooring.

CAUTION

Without the Inlet Cowl Cover, water, dust or wind can go inside the Engine.

- > Water retention: accelerates corrosion.
- > Dust: the Engine could be damaged during the ignition.
- > Wind: allows blade rotation which may cause damage.

The Engine warranty may be void if the Covers are not used properly under the required conditions and there is damage to the Engine.



DIMENSIONS
500 x 400 x 400 mm
[20 x 16 x 16 in]

WEIGHT
3 kg [7 lbs]

The pictures, measurements, and weights shall be used only as an indication.

7

347-1100-4GSE



A220 GSE TOOLS



THRUST REVERSER SLING - LH/RH

DESCRIPTION - USE

The Thrust Reverser Sling is used to pick the Thrust Reverser Engineering Assembly (Both LH/RH) from the ACFT / Shipping container and place the same on the Thrust Reverser Dolly for maintenance purpose. The Manual Hoist connected to the Latch beam location Via the Nylon Strap can be operated to tilt the TR Engineering assembly at various angles during Removal and Installation from ACFT onto the dolly and vise-versa.

CAUTION

This tool is the only tool validated to lift the E190-E2 Thrust Reverser. If the Thrust Reverser is lifted using another tool, and there is damage, the insurance may not cover the damage.

TEST


Dedienne Aerospace has regional facilities to aid in the required annual testing and recertification.

DIMENSIONS
1250 x 1400 x 550 mm
[50 x 56 x 22 in]

WEIGHT
150 kg [331 lbs]

The pictures, measurements, and weights shall be used only as an indication.

8



347-3001-1GSE



A220 GSE TOOLS



THRUST REVERSER TOWABLE DOLLY - LH/RH

DESCRIPTION - USE

This Tool is used to carry a LH or RH Thrust Reverser.

CAUTION

When the Thrust Reverser is removed from the aircraft using the Thrust Reverser Sling, the Thrust Reverser Dolly is needed to store or work on the Thrust Reverser.



DIMENSIONS
2600 x 2400 x 1000 mm
[103 x 95 x 40 in]

WEIGHT
750 kg [1,653 lbs]

The pictures, measurements, and weights shall be used only as an indication.


347-3001-2GSE



THRUST REVERSER BEAM BOLT THREAD PROTECTOR

DESCRIPTION - USE

This Tool is used to protect thread of Thrust Reverser Hinge Beam Bolts during Bolt Removal and Installation.



DIMENSIONS
250 x 250 x 150 mm
[10 x 10 x 6 in]

WEIGHT
1,5 kg [4 lbs]

The pictures, measurements, and weights shall be used only as an indication.

347-3001-3GSE





THRUST REVERSER PLUG

DESCRIPTION - USE

This tool is used to cover the bypass duct between the Translating Sleeve and Inner Fixed Structure (LH and RH).

CAUTION

Without the Inlet Cowl Cover, water, dust or wind can go inside the Engine.

> Water retention: accelerates corrosion.

> Dust: the Engine could be damaged during the ignition.

> Wind: allows blade rotation which may cause damage.

The Engine warranty may be void if the Covers are not used properly under the required conditions and there is damage to the Engine.



DIMENSIONS

1400 x 600 x 450 mm
[56 x 24 x 18 in]



WEIGHT

40 kg [89 lbs]

The pictures, measurements, and weights shall be used only as an indication.

11

347-3001-5GSE



A220 GSE TOOLS



THRUST REVERSER DOOR OPENING SYSTEM, HAND PUMP

DESCRIPTION - USE


This tool is used for manual actuation of Thrust Reverser Door Actuation System.

CAUTION

The Thrust Reverser Hydraulic Opening System or pump has been designed for use on the E190-E2. If another pump is used to open the C-Ducts and there is damage, the insurance may not cover the damage.

TEST

Dedienne Aerospace has regional facilities to aid in the required annual testing and recertification.



DIMENSIONS

1050 x 700 x 1350 mm
[42 x 28 x 54 in]



WEIGHT

160 kg [353 lbs]

The pictures, measurements, and weights shall be used only as an indication.

12

347-3001-7GSE



A220 GSE TOOLS



THRUST REVERSER UNLOCK PINS LH/RH

DESCRIPTION - USE

These Pins are used to unlock TRAS Actuators and Track Lock for both LH & RH Nacelles during maintenance.



DIMENSIONS
500 x 300 x 300 mm
[20 x 12 x 12 in]

WEIGHT
3 kg [7 lbs]

The pictures, measurements, and weights shall be used only as an indication.

13



347-3001-11GSE


A220 GSE TOOLS



THRUST REVERSER PRD TORQUE ADAPTOR

DESCRIPTION - USE

This Tool is used for check pressure relief door latch pressure.



DIMENSIONS
400 x 300 x 200 mm
[16 x 12 x 8 in]

WEIGHT
2 kg [5 lbs]

The pictures, measurements, and weights shall be used only as an indication.

14

347-3001-14GSE



A220 GSE TOOLS



TRANSLATING SLEEVE DOLLY

DESCRIPTION - USE

This Tool is used during the maintenance and transportation of transleeve assembly.

CAUTION

When the Translating Sleeve is removed from the aircraft using the Thrust Reverser Sling, the Translating Sleeve Dolly is needed to store or work on the Translating Sleeve.



DIMENSIONS
2700 x 1950 x 1300 mm
[107 x 77 x 52 in]

WEIGHT
440 kg [970 lbs]

The pictures, measurements, and weights shall be used only as an indication.

15

347-3501-2GSE



A220 GSE TOOLS



FAN COWL DOOR SLING

DESCRIPTION - USE

The Fan Cowl Door Sling is used for E190-E2 series Fan Cowl Removal & Installation only.

CAUTION

This Sling is a lifting tool and it is the only tool validated to lift the E190-E2 Fan Cowl. If the Fan Cowl is lifted with another tool, and there is damage, the insurance may not cover the damage.



DIMENSIONS
800 x 450 x 350 mm
[32 x 18 x 14 in]

WEIGHT
70 kg [155 lbs]

The pictures, measurements, and weights shall be used only as an indication.

16

347-2000-1GSE



A220 GSE TOOLS




FAN COWL DOLLY

DESCRIPTION - USE

The Fan Cowl Dolly is used to move the Fan Cowl in the hangar or shop and for Fan Cowl Storage. The Fan Cowl can be maintained or stored on the Fan Cowl Dolly.

CAUTION

After using the Fan Cowl Sling 347-2000-1GSE to remove a Fan Cowl from the Engine, the Fan Cowl Dolly is needed to move, store or do maintenance on the Fan Cowl.



DIMENSIONS
3100 x 1700 x 1300 mm
[123 x 67 x 52 in]

WEIGHT
350 kg [772 lbs]

The pictures, measurements, and weights shall be used only as an indication.

17

347-2000-2GSE



A220 GSE TOOLS



FAN COWL VENT DOOR PLUG

DESCRIPTION - USE

The Fan Cowl Vent Door Plug is used to prevent foreign objects from entering into the Fan Cowl when the aircraft is in parking or mooring.



DIMENSIONS
550 x 450 x 250 mm
[22 x 18 x 10 in]

WEIGHT
5 kg [12 lbs]

The pictures, measurements, and weights shall be used only as an indication.

18

347-2000-3GSE


A220 GSE TOOLS



FAN COWL HINGE BOLT THREAD PROTECTORS

DESCRIPTION - USE

This tool is used to protect the Hinge Bolt Threads of the Fan Cowl Hinge pins during Removal & Installation.



DIMENSIONS
300 x 300 x 150 mm
[12 x 12 x 6 in]

WEIGHT
2 kg [5 lbs]

The pictures, measurements, and weights shall be used only as an indication.

19

347-2000-5GSE



A220 GSE TOOLS



EXHAUST NOZZLE AND CENTERBODY COVER

DESCRIPTION - USE

This tool is used to cover exhaust exit area and cover the AFT Centerbody.

CAUTION

Without the Inlet Cowl Cover, water, dust or wind can go inside the Engine.

- > Water retention: accelerates corrosion.
- > Dust: the Engine could be damaged during the ignition.
- > Wind: allows blade rotation which may cause damage.


The Engine warranty may be void if the Covers are not used properly under the required conditions and there is damage to the Engine.

DIMENSIONS
1200 x 500 x 400 mm
[48 x 20 x 16 in]

WEIGHT
40 kg [89 lbs]

The pictures, measurements, and weights shall be used only as an indication.

20



347-4100-1GSE



A220 GSE TOOLS



EXHAUST NOZZLE LIFTING AID

DESCRIPTION - USE

This tool is used to Remove or Install Exhaust Nozzle Assembly.

CAUTION

This Aid is a lifting tool and it is the only tool validated to lift the E190-E2 Nozzle. If the Nozzle is lifted with another tool, and there is damage, the insurance may not cover that damage.

TEST

Dedienne Aerospace has regional facilities to aid in the required annual testing and recertification.

DIMENSIONS
1600 x 1200 x 1300 mm
[63 x 48 x 52 in]

WEIGHT
200 kg [441 lbs]



The pictures, measurements, and weights shall be used only as an indication.

21



A220 GSE TOOLS

347-4100-4GSE




ENGINE MOUNT CART

DESCRIPTION - USE

This Tool is used for Engine Mount Assembly Transportation & Maintenance.

DIMENSIONS
2000 x 1100 x 1300 mm
[79 x 44 x 52 in]

WEIGHT
280 kg [618 lbs]



The pictures, measurements, and weights shall be used only as an indication.

22

A220 GSE TOOLS

347-6000-1GSE



FWD ENGINE MOUNT SLING

DESCRIPTION - USE

This Tool is used to lift and move the FWD Engine Mount Assy.

CAUTION

This FWD Engine Mount Sling is a lifting tool and it is the only tool validated to lift the E190-E2 FWD Engine Mount. If the Engine Mount is lifted with another tool, and there is damage, the insurance may not cover the damage.

TEST

Dedienne Aerospace has regional facilities to aid in the required annual testing and recertification.

DIMENSIONS

550 x 450 x 250 mm
[22 x 18 x 10 in]

WEIGHT

9,8 kg [22 lbs]



The pictures, measurements, and weights shall be used only as an indication.

23

347-6001-2GSE



A220 GSE TOOLS



AFT ENGINE MOUNT SLING

DESCRIPTION - USE

This Tool is used to lift and move the AFT Engine Mount Assy.

CAUTION

This AFT Engine Mount Sling is a lifting tool and it is the only tool validated to lift the E190-E2 AFT Engine Mount. If the Engine Mount is lifted with another tool, and there is damage, the insurance may not cover the damage.

TEST

Dedienne Aerospace has regional facilities to aid in the required annual testing and recertification.

DIMENSIONS

600 x 250 x 400 mm
[24 x 10 x 16 in]

WEIGHT

14 kg [31 lbs]



The pictures, measurements, and weights shall be used only as an indication.

24

347-6501-1GSE

A220 GSE TOOLS



SALES & TECHNICAL SUPPORT

PROGRAM MANAGEMENT	nacelletooling@dedienne-aero.com	
01 NORTH & SOUTH AMERICAS	sales.americas@dedienne-aero.com	support.americas@dedienne-aero.com
02 EUROPE	sales.europe@dedienne-aero.com	support.europe@dedienne-aero.com
03 MIDDLE EAST & AFRICA	sales.mea@dedienne-aero.com	support.mea@dedienne-aero.com
04 INDIA	sales.india@dedienne-aero.com	support.india@dedienne-aero.com
05 SINGAPORE & ASIA PACIFIC	sales.sea@dedienne-aero.com	support.sea@dedienne-aero.com
06 CHINA & HONG-KONG	sales.cn@dedienne-aero.com	support.cn@dedienne-aero.com

PRODUCTION FACILITIES & SERVICE CENTERS

AMERICAS	USA MIAMI ■ 2500 NW 74. Ave Miami - FL 33122 +1 305 716 83 00	USA CINCINNATI ▲ 4330 Batavia road Batavia - Ohio +1 513 658 75 45	MEXICO ■ Av. de las Fuentes No. 106 Int. 12 y 13 Col. Parque Industrial Bernardo Quintana C.p. 76246 El Marqués, Querétaro +52 442 824 35 57
	FRANCE TOULOUSE ■ ZAC de Saint-Martin 5, rue Gaye Marie 31300 - Toulouse +33 5 61 06 77 79	FRANCE PARIS ▲ Aéroport Paris-Villaroche, Zone Nord, bâtiment A08 77950 - Montreuil-Sur-Le-Jard +33 6 28 10 76 79	UNITED KINGDOM ▲ Unit 28 Eagle Park - Alfreton Road Derby, Derbyshire DE21 4AE +44 133 261 38 28
EUROPE	IRELAND ▲ 9/10 Beechpark Logistics Smithstown, Shannon Co.Clare +35 38 606 728 98	GERMANY ▲ Schützenwall 37-41 22844 Norderstedt +49 40 66 89 29 72	
	UNITED ARAB EMIRATES ■ Warehouse FZS1AC01 South Zone, Jebel Ali Free Zone P.O. Box: 18056 - Dubai +971 4 295 0071	QATAR ▲ LIU LG 33-35 Um Al Houl Free Zone P.O Box # 30661 - Doha +974 50 58 67 87	
MIDDLE EAST & AFRICA	SINGAPORE ■ 1 Seletar Aerospace Lane Singapore 797435 +65 62 62 59 79	INDIA ■ Regus, Beech E-1, Manyata Embassy Business Park, Outer Ring Road, Nagavara, Bengaluru - 560045 +91 82 17 588 075	
	CHINA & HONG KONG ■ N°5 Jintiang Road Hongqi town - Jinwan Zone 519090 Zhuhai City Guangdong +86 756 893 6510	HONG KONG ▲ 806 Capitol Centre 5-19 Jardine's Bazaar Causeway Bay +86 756 893 6510	



WEBSITES & SOCIAL MEDIAS



DEDIENNE-AERO.COM



LEAPTOOLING.COM



NACELLETOOLING.COM





WWW.NACELLETOOLING.COM